

## Classic™ Gauge Panel EZ as 1, 2, 3





Connect the "white capped" barb to the "white capped" valve marked DEL using 1/4" air line. Make sure you connect left to left and right to right.



Connect "red capped" barb to red head on gauge using 1/4" air line. Make sure you connect left to left and right to right.



Connect both "black capped" barbs marked SUP to the Wye fittings using 1/4" air line.



Complimentary wire harness ties into your fuse box/panel to light up your gauge. Connect red female terminal to LED buld and then to your fuse panel. Connect black female terminal to LED buld and then to ground.