

**Vehicle: Diagrams****Text Description of Ground Locations**

<b>GROUND</b>	<b>LOCATION</b>
G100 (2.2L Engine)	Lower RH front of engine block
G100 (4.3L Engine)	Lower RH front of engine block
G101 (2.2L Engine)	Lower RH radiator support
G101 (4.3L Engine)	LH rear of engine compartment to the left of the A/C compressor relay
G102 (2.2L Engine)	LH side of engine below exhaust manifold
G102 (4.3L Engine)	RH rear of engine, on head
G103 (4.3L Engine)	RH rear of engine, on head
G104 (4.3L Engine)	LH rear portion of cylinder head
G105 (4.3L Engine)	LH rear portion of cylinder head
G106	Battery harness, RH front frame near wheel speed sensor connector
G107 (2.2L Engine)	RH forward lower engine block
G107 (4.3L Engine)	Lower engine block, below water pump
G108	Battery harness, RH radiator support
G109	Fog lamp harness, LH radiator support
G110	Forward lamp harness, RH radiator support
G111	Forward lamp harness, RH radiator support
G112	Fog lamp harness, LH radiator support
G113	LH rear of engine compartment to the left of the A/C compressor relay, 2.2L engine
G114	LH rear engine, below crankshaft position sensor, 2.2L engine
G115	LH rear engine, below crankshaft position sensor, 2.2L engine
G116	LH side of engine below exhaust manifold, engine harness, 2.2L engine
G118	LH side of engine below exhaust manifold, engine harness 2.2L engine
G125	On LH radiator support
G126	On RH radiator support
G130	On LH Radiator support
G132	LH side of engine below exhaust manifold, engine harness, 2.2L engine
G180 (2.2L Engine)	Lower LH radiator support
G180 (4.3L Engine)	Lower RH radiator support
G402	LH rear of chassis frame on cross member
G410 (Pickup)	LH rear of chassis frame near trailer wiring provision
G410 (Utility)	Inside LH rear frame rail on crossmember
G420 (Utility)	RH D-pillar near tail lamp
G452 (Pickup)	LH rear of chassis near trailer wiring provision
G452 (Utility)	LH D-pillar near tail lamps