

LOCATION OF PARTS




TD01309B G

1. Clutch Lever
2. Left Handlebar Switches
3. Clutch Fluid Reservoir
4. Meter Instruments
5. Brake Fluid Reservoir (Front)
6. Right Handlebar Switches

7. Throttle Grip
8. Front Brake Lever
9. Spring Preload Adjuster
10. Rebound Damping Force Adjuster (Front Fork)
11. Ignition Switch/Steering Lock

14 LOCATION OF PARTS




TD013158 G

1. Headlight
2. Air Cleaner Intake
3. Turn Signal Light
4. Air Cleaner
5. Spark Plugs
6. Fuel Tank
7. Seat
8. Seat Lock
9. Single Seat Cover

10. Tail/Brake Light
11. License Plate Light
12. Brake Disc
13. Rebound Damping Force Adjuster
14. Front Fork
15. Brake Caliper
16. Coolant Reserve Tank
17. Shift Pedal

18. Side Stand
19. Compression Damping Force Adjuster
20. Chain Adjuster
21. Drive Chain
22. Muffler



TD01317B G

1. Fuse Box
2. Brake Fluid Reservoir (Rear)
3. Battery
4. Fuel Tank Cap
5. Swingarm

6. Rear Brake Light Switch
7. Rear Brake Pedal
8. Rear Shock Absorber
9. Oil Level Inspection Window