

- 1) Remove the old clamps and rack boot from the passenger side of the rack.
- 2) Unscrew and remove the inner tie rod from the rack. You may need to drill out the locking pins which are driven into the nuts.
- 3) Thread the new 2" rack extension into the end of the rack.
- 4) Thread the inner tie rod end onto the end of the rack extension and tighten the entire assembly.
- 5) Secure the rack extension to the rack and the inner tie rod to the rack extension by drilling a 1/8" diameter hole 3/8" deep using the starter holes provided. Stake by driving in the 1/8" x 3/8" roll pin supplied.
6. Slide the new extended rack boot over the tie rod and on to the rack housing. Secure the boot to the rack on the end with the zip ties supplied.

